


20" Bike Spinner assembly instructions



Step 1

Slide the narrow, plastic tipped end of the Upper Support Pole into Star Lock Hub. Push down on the hub until the Upper Support Pole locks into place and can not be removed. (Diagram A)

Step 2

Connect the Main Internal Body Strut to the Bike Frame Strut Assembly as shown in diagram A. Attach all Velcro tabs on the inside of the Body Sleeve to the corresponding Velcro tabs on the Bike Frame.

Step 3




Slide one of the Axles onto the rear axle fitting. The axle can point either to the right or left but not to the top or bottom since this is where the wheel will sit. Place an threaded Axle Lock Nut after it and tighten. Repeat with the front axle fitting making sure the axle is pointed the same direction as the rear axle. (Diagram B)

Step 4

Slide one wheel onto each axle and tap the axle caps onto the ends of the axles using a mallet or a piece of wood. (Diagram C)

Step 5

Drive Ground Stake into ground and insert non-ferruled end of the Lower Support Pole into Ground Stake. Insert the Upper Pole Section of completed Bike Spinner into ferrule on top of Lower Support Pole. (Diagram D)



PLEASE NOTE: Although your Bicycle Spinner is constructed with UV resistant SunTex™ fabric, it is recommended that you take it inside during storms and harsh weather to preserve its durability.