



Step 1
Identify gores and support poles (Diagram A).

Step 2
Attach the Upper Gore. Stretch the set of gores so they are now surrounding the Top Support Pole. Starting with panel A of the Upper Gore, insert each gore strut into the strut holes on the top and bottom disc of the upper and lower hub (Diagram B).

Step 3
Repeat Step 2 to assemble the Bottom Gore.

Step 4
Next, connect the Upper and Lower Support Pole. Slide the Upper Support Pole through the Upper Hub on the Lower Support Pole. Then insert the Upper Support Pole into the ferrule of the Lower Support Pole (Diagram C).

Step 4
Please note that if a mistake is made putting in the panels, they can be removed by unscrewing the hub. Use a small phillips or flathead screwdriver.

