


German Shepherd *assembly instructions*



Step 1


Remove Cotter Pin and slide one Nylon Washer from the Spinner Axle.

Step 2

Slide Spinner Wings onto the Spinner Axle and replace the Nylon Washer.

Step 3

Install the Rear Body Section and slide the Cotter Pin through the hole in the Body Ferrule and bend the ends outward to secure in place.



Step 4

Slide the narrow tip of the Upper Support Pole into Hub. Push the Support Pole firmly down until it locks into place and cannot be removed. This best done with the base of the Upper Support Pole on a hard surface and using a mallet or block of wood to trap into place.

Step 5

Connect Upper Support Pole with Lower Support Pole and insert into the ground.

PLEASE NOTE: *It is recommended that you take your Petite Spinner inside during storms and harsh weather to preserve its durability.*