

#25673 BIKER PARROT SPINNER ASSEMBLY INSTRUCTIONS

1. The Strut Assembly of your Biker Parrot Spinner is shipped in three sections. Connect Center Hub to Rear Strut Assembly and Front Strut Assembly by joining ends of Ferrule Connectors as shown. (Diagram A)
2. Open all velcro straps. Slide the completed Strut Assembly into bottom of Motorcycle Body Sleeve. Connect hub into the main vertical strut inside the parrot. Reclose all velcro straps. Attach velcro connectors inside of Motorcycle Body Sleeve near Rear Wheel Assembly. Close velcro pockets on both sides of Motorcycle Body Sleeve over side rods of Rear Wheel Assembly. Attach velcro tabs on inside of both tailpipe sections on Motorcycle Body Sleeve to Velcroed Axle Caps on Rear Wheel Assembly. (Diagram B)
3. Drive Ground Stake into ground. Slide Support Pole into Ground Stake. Insert Upper Pole Section of completed Biker Parrot Spinner into ferrule on top of Support Pole. (Diagram C)

PLEASE NOTE: Although your Garden Spinner is constructed with UV resistant SunTex™ fabric, to preserve its durability, we recommend taking the Spinner inside during harsh weather or when not in use.

