

# Assembly Instructions

## Step 1

Extend the Body Strut horizontally and make sure it seats into the Rotating Hub.

## Step 2

A Neck Rod and Ferrule should already be installed inside the Head. Stick the Head onto the Vertical Mast and connect it to the Neck Rod with the Ferrule. Attach Head to the Body using the Velcro Flaps.

## Step 3

Drive Plastic Stake into ground. Insert the Vertical Mast into Ground Stake.

Compatible with Premier's 6 mm Deck Mount (sold separately).

