

Wind Garden by premier designs



B Upper Support Pole Ferrule Lower Support Pole Ground Stake Ground



Triple Spinner assembly instructions

Your Triple Spinner Flag Pole is a great way to add spectacular spinning motion to any standard garden flag!

Step 1

Slide the spacers and the three main spinning wheels onto the Spinner Wheel Axle in the order shown (Diagram A). Slide the Large Wheel, then one Spacer, then the Medium Wheel, then the second Spacer and followed by the Small Wheel. Once you are sure you have the wheels and spacers on the Spinning Wheel Axle exactly like the diagram, take the Lock Nut and push it firmly on the front of the Spinning Wheel Axle to secure wheels. You may find it is easier to tap the lock nut on the axle with a block of wood or small hammer. Once the Lock Nut is in place, spread the spacers and wheels out so they spin freely.

Step 2

Drive Ground Stake into the ground and insert the Lower and Upper Ground Support Poles.

Step 3

Insert the Spinner Assembly into the Upper Support Pole. You are now ready to install your garden flag. (Diagram B)

Step 4

Insert the garden flag of your choice onto the Flag Support Rod. Insert the Flag Support Rod into the Flag Support Rod Ferrule and install Cotter Pin to secure rod.

Step 5

Attach Flag Retaining U-Clips over the flag sleeve to secure the garden flag to the Flag Support Rod. (Diagram C)

