

#26343 RED VINTAGE RACER RACE CAR SPINNER ASSEMBLY INSTRUCTIONS

1. The Strut Assembly of your Racer spinner is shipped in three sections. Connect Center Rods of the Rear Strut Assembly and the Front Strut Assembly to the Star Lock Hub as shown. Open Velcro straps and insert completed Strut Assembly into bottom of Racer Sleeve as shown. Insert the 9.5mm Support Pole into the Star Lock Hub. Reclose Velcro straps. (Diagram A)
2. Take one of the Spinner Axles and slide it onto the Rear Strut Assembly at back of Racer Body. Tighten the knob on the "T" Joint to hold the Axles to the Struts. (Diagram B)
3. Take one of the four Spinner Wheels and slide it onto one of the two Spinner Axles. Slide second Spinner Wheel onto Spinner Axle. Pound second Axle Cap onto uncapped end of Spinner Axle using a mallet or piece of wood. (Diagram C)

PLEASE NOTE: Spinner Wheels on same side of Racer should spin in same direction and Spinner Wheels on same axle should spin in opposite directions. Before putting second Axle Cap into place, make sure wheels spin as shown in Diagrams C and D.

4. Repeat Step 3 using second Spinner Axle and the two remaining Spinner Wheels to assemble the front Spinner.
5. Pound Ground Stake into ground and insert non-ferruled end of Support Pole into Ground Stake. Insert Upper Pole Section of completed Racer Spinner into ferrule on top of Support Pole. (Diagram D)

PLEASE NOTE: Although your Race Car Spinner is constructed with UV resistant SunTex™ fabric, it is recommended that you take it inside during storms and harsh weather to preserve its durability.

