

- Your Premier Bike Flag Pole is built with convenient shock cording for easy assembly.
- In addition, your Bike Flag Pole comes with an adjustable clamp that will secure your flag to the pole. **Make sure you secure your flag to the pole using the retaining cord and clamp.**

Pole Clamp Adjusting:

- The metal tabs on the retaining clamp are spring loaded and can easily be opened with any basic pliers by squeezing together the two metal tabs on the retaining clamp. (See diagram A)
- Once you have moved the metal retainer clamp off of the rubber bushing, slide the bushing up or down the pole to the desired location. (See diagram B)
- Using the pliers to open the metal retaining clamp by squeezing again on the metal tabs, slide the retaining clamp over the rubber bushing and release the tabs. The retaining ring will constrict on the rubber bushing and hold it into place. (See diagram C & D)

Attaching Flag or Windsock:

- Pass the flag retaining cord through the hole on the metal retaining clamp and tie it to the other end of the cord. You may use any secure knot such as a square knot or two overhand knots. You may also use a simple bow knot like you would tie a pair a shoes (See diagram E). For windsock style flag simply clip on to Cord Loop (See diagram G).

For Special Cases Where the Pole Clamp Needs to be Raised Above the Metal Ferrules:

- If you have a shorter style flag that you would like to secure above the first or second metal ferrule, it is possible to re-position the Pole Clamp above the metal ferrules by putting a slit in the rubber bushing. You can put a slit in the rubber bushing by using a simple hand scissors. (See diagram F)
- Once you reposition the rubber bushing above the metal ferrules and in the desired location, simply re-install the metal clamp using a pliers per the above instructions. Please note the metal retaining clamp can easily “jump” over the metal ferrules to whatever position on the pole you wish. (See diagram H)

