







sku #22363

Completed Internal Strut Assembly.
Make sure all parts connect as shown.



Step 1

The Strut Assembly of your Lighthouse spinner is shipped in two sections. Connect support pole (with ferrule end up) to internal strut assembly through small opening in the bottom of the Lighthouse body as shown. (diagram A)



Step 2

Take the Spinner Axles and insert it through the opening so that the vertical portion of "T" Joint aligns with the vertical strut of the Internal Strut Assembly at the top of the Lighthouse body. (diagram B) Slide the vertical portion of "T" Joint onto the vertical strut of the Internal Strut Assembly. Tighten the knob on the "T" Joint to hold the Axle to the Strut. (diagram C)

Step 3

Take one of the two Spinner Wheels and slide it onto one of the Spinner Axles. Slide second Spinner Wheel onto Spinner Axle. (**Note: Spinner Wheels on same axle should spin in opposite directions. Before putting Axle Caps into place, make sure wheels spin as shown in diagram D.**) Pound Axle Cap onto uncapped end of Spinner Axle using a mallet or piece of wood. (diagram D)

Step 4

Pound Ground Stake into ground and insert non-ferruled end of Support Pole into Ground Stake. (diagram E)

PLEASE NOTE: Although your Lighthouse Spinner is constructed with UV resistant SunTex™ fabric, it is recommended that you take it inside during storms and harsh weather to preserve its durability.