




# GOOGLEFLEX *assembly instructions*

**Step 1:**  
 Unfold the kite so it makes a square with all tensioning lines in the center and Tow Loop on top. Set aside the Spine struts. (diagram A)

**Step 2:**  
 Assemble the Spine and slide it through each of the rings starting with the topmost ring in the center of the kite and into the Lower Spine Cup. (diagram B)

**Step 3:**  
 Carefully pull back the Upper Spine Cup along the spine. The kite will automatically take shape as you pull back on the Upper Spine Cup. Make sure rings do not get caught on the Spine ferrule as you pull. Place the Upper Spine Cup over the end of the spine. Adjust tensioning lines as needed so that all lines are even. (diagram C)

**Step 4:**  
 Attach the Tail clip to any of the loops around the Lower Spine Cup. Attach the flying line to the Tow Loop. (diagram C)



**To Fly:** Have a friend stand about 75 ft. downwind from you and hold the kite with its Leading Edge pointed towards the sky. As the wind catches the kite, signal your friend to release it while you bring in the line with long steady pulls. Slowly let out more line as the kite flies upward.

## OPTIMUM WIND CONDITIONS FOR GOGLEFLEX

RECOMMENDED LINE: 50 LB TEST LINE

BEAUFORT SCALE	CALM	LIGHT AIR	LIGHT BREEZE	GENTLE BREEZE	MODERATE BREEZE	FRESH BREEZE	STRONG BREEZE
	smoke rises vertically	Direction of wind shown by smoke, but not by wind vanes	Wind felt on face, leaves rustle, ordinary vane moves	Leaves and small twigs in constant motion; wind extends light flag	Raises dust and loose paper; small branches move	Small trees & leaves begin to sway; crested wavelets form on inland water	Large branches in motion; utility wire whistle; windows rattle
WIND [M.P.H.]	0	1 2 3	4 5 6 7	8 9 10 11 12	13 14 15 16 17 18	19 20 21 22 23 24	25 26 27 28 29 30
<b>GOOGLEFLEX</b>							

Note: Wind conditions aloft may vary considerably from those found near ground level.