

## Step 1

The strut assembly of your ball spinner consists of one upper rod as shown. There are two of each Panel A, B, and C. (diagram A)

## Step 2

Starting with one of Panel A, insert the rod at the top end of the panel into one of the pre-drilled holes in the upper hub. Then insert the rod at the bottom end of the panel into the corresponding pre-drilled hole in the lower hub. When inserting the Rods, be careful to push them all the way into the holes so they do not snap out. (diagram B)

## Step 3



Moving counter clock-wise to the next pre-drilled holes in the upper and lower hub, repeat step 2 for inserting the next panel. Alternate between Panel A, B, and C as shown. (diagram C)

## Step 4

Repeat steps 2 and 3 moving clock-wise around the upper rod until all panels are attached. Each additional panel should overlap the one next to it (diagram D). See top view of completed Ball Spinner. (diagram E)

## Step 5

Pound Ground Stake into ground and insert non-ferruled end of Support Pole into Ground Stake. Insert Upper Rod Section of completed Ball Spinner into ferrule at top of Support Pole. (diagram F)



**PLEASE NOTE:** Although your Rooster Ball Spinner is constructed with UV resistant SunTex™ fabric, it is recommended that you take it inside during storms and harsh weather to preserve its durability.