


# Flame Motorcycle Spinner *assembly instructions*

sku # 25656




## Step 1

The Strut Assembly of your Motorcycle Spinner is shipped in three sections. Connect Center Rods of the Rear Strut Assembly and the Front Strut Assembly to the Center Rod of the Center Strut Assembly as shown. (diagram A)

## Step 2

Open all Velcro straps and slide completed Strut Assembly into bottom of Motorcycle Body Sleeve as shown. Reclose all Velcro straps. (diagram B)





## Step 3

Attach Velcro connectors inside of the Motorcycle Body Sleeve. The velcro will go over the side rods of the Rear Wheel Assembly. Axle rod needs to be slid through the tailpipe rods. Slide the wheels onto the spinner axle. Attach velcro tabs on inside of both tailpipe sections on Motorcycle Body Sleeve to Velcroed Axle Caps on Rear Wheel Assembly. (diagram B inset).

#### Step 4

Attach velcro connectors on the inside of the Motorcycle Body Sleeve over the Front Struts of the Front Strut Assembly. Slide wheel onto axle.

Attach velcro tabs on the inside of the Motorcycle Body Sleeve to the velcroed Axle Caps on the Front Wheel Assembly. (diagram C)



#### Step 5

Pound Ground Stake into ground and insert non-ferruled end of Support Pole into Ground Stake. Insert Upper Pole Section of completed Motorcycle Spinner into ferrule on top of Support Pole.

(diagram D)

**PLEASE NOTE:** Although your Flame Motorcycle Spinner is constructed with UV resistant SolarMax™ fabric, it is recommended that you take it inside during storms and harsh weather to preserve its durability.