




36" VW Bus Spinner *assembly instructions*

sku #26824






Step 1

The Strut Assembly of your VW Bus spinner is shipped in three sections. Connect Center Rod of the Back Strut Assembly to the Center Hub as shown. (diagram A)

Step 2

Open Velcro seam and insert the Completed Rear Strut Assembly into the VW Bus Body Sleeve. Once inside the Sleeve, connect the Front Strut Assembly (already contained inside the Body Sleeve) to the Center Hub of the Completed Rear Strut Assembly. Reclose Velcro seam. (diagram B)



Step 3

Take one of the Spinner Axles and slide it onto the Rear Strut Assembly at back of VW Bus Body. Tighten knob on the "T" Joint to hold the Axles to the Struts. (diagram C)

Step 4

Take one of the four Spinner Wheels and slide it onto one of the two Spinner Axles. Slide second Spinner Wheel onto Spinner Axle. **(Note: Spinner Wheels on same side of Bus should spin in same direction and Spinner Wheels on same axle should spin in opposite directions. Before putting second Axle Cap into place, make sure wheels spin as shown in diagrams D and E.)** Pound second Axle Cap onto uncapped end of Spinner Axle using a mallet or piece of wood. (diagram D)

Step 5

Repeat Step 4 using second Spinner Axle and the two remaining Spinner Wheels to assemble the front Spinner.

Step 6

Pound Ground Stake into ground and insert non-ferruled end of Support Pole into Ground Stake. Insert Upper Pole Section of completed VW Bus Spinner into ferrule on top of Support Pole. (diagram E)

PLEASE NOTE: Although your VW Bus Spinner is constructed with UV resistant SunTex™ fabric, it is recommended that you take it inside during storms and harsh weather to preserve its durability.