



11 ft. Shark

assembly instructions





open your new kite:

- Remove rubber bands from bundled kite and struts. Group the struts according to Diagram A.
- Unroll kite and spread it out with struts facing up. The wing struts are pre-installed in the leading edge of the kite. The loose Spine Strut should be inserted into the ferrule at the bottom of the pre-installed Spine Strut. Then insert the bottom of the assembled Spine Strut into the Lower spine pocket. (Diagram B)

install struts:



- Insert the Cross Strut into the Cross Strut Pockets at the leading edge. (Diagram C)





install struts (cont.):

- Assemble the 2 Head Stiffener Struts by sliding strut end into the adjacent Ferrule ensuring that it is fit snugly. On the head of the kite along the leading edge just below the Spine Pocket is the Strut Opening. **The opening is a space in the stitching where the fabric can be slightly lifted.** Bend the assembled strut and insert both tips into the Strut Openings, then slide it down a little on each side, careful not to get the ferrules caught on the fabric, until both sides of the strut are all the way down into the sleeves. (Diagram D, E)



to fly:

- Have a friend stand about 75 feet downwind from you and hold the kite with its nose pointed towards the sky. As the wind catches the kite, signal your friend to release it while you steadily pull in line until the kite is aloft. As the kite flies upward, slowly release more line.