


EXOTIC BIRD

assembly instructions



Step 1:



Unroll kite and lay out flat facedown.

Step 2:

Assemble leading edges by sliding Outer Leading Edge Rods into Leading Edge Sleeves and inserting into Inner Leading Edge Rods. (diagram A)

Step 3:

Insert both Inner Leading Edge Rods into Dihedral at Spine Rod. (diagram A)



Step 4:

Stretch Leading Edge Sleeve to ends of Outer Leading Edge Rods and hook Bungee Lines over Arrow Nocks. (diagram B)

Step 5:

Slip the shorter of the two Shaping Rods behind Spine Rod and into pockets on eyes. Repeat with longer Shaping Rod and pockets on edges of tail. (diagram C)

FLIGHT INSTRUCTIONS:

- Tie flying line to Tow Loop.
- Have a friend stand about 75 ft. downwind from you and hold the kite with its head pointed towards the sky.
- As the wind catches the kite, signal your friend to release it while you bring in the line with long steady pulls.
- Slowly let out more line as the kite flies upward.


RECOMMENDED LINE: 80 LB TEST LINE

Step 6:

Attach Ribbon Tail at Tail Attachment Point. (diagram C)

Step 7:

Attach line to one of the three Tow Points, and your Exotic Bird is now ready to fly! (diagram D)



OPTIMUM WIND CONDITIONS FOR EXOTIC BIRD

BEAUFORT SCALE	CALM	LIGHT AIR	LIGHT BREEZE	GENTLE BREEZE	MODERATE BREEZE	FRESH BREEZE	STRONG BREEZE
WIND [M.P.H.]	0	1 2 3	4 5 6 7	8 9 10 11 12	13 14 15 16 17 18	19 20 21 22 23 24	25 26 27 28 29 30
	smoke rises vertically	Direction of wind shown by smoke, but not by wind vanes	Wind felt on face, leaves rustle, ordinary vane moves	Leaves and small twigs in constant motion; wind extends light flag	Raises dust and loose paper; small branches move	Small trees & leaves begin to sway; crested wavelets form on inland water	Large branches in motion; utility wire whistle; windows rattle
EXOTIC BIRD							

Note: Wind conditions aloft may vary considerably from those found near ground level.