

ZOMBIE KITE assembly instructions

ASSEMBLY

Step 1:

Remove the kite from the bag and Unroll.

Step 2:

Insert the Spine Strut into the Ferrule and Spine Pocket. Make sure that the the Dihedral Fitting is twisted so that it is pointing up. The Dihedral fitting has a built in angle, it should be in a position so that when the Arm Stiffeners are inserted they sweep backwards from the front of the Kite. (diagram A and B)

Step 3:

Slide the Arm Stiffeners into the Arm Sleeves. Insert into the Dihedral Fitting. (diagram A)

Step 4:

Remove Rubber Bands from the Tails. (diagram A)

FLYING

Step 1:

Attach flying line to tow point on the Bridle. (diagram C)

Step 2:


Have a friend stand about 75 feet downwind from you and hold the kite with its nose pointed towards the sky.


Step 3:


As the wind catches the kite, signal your friend to release it while you steadily pull in line until the kite is aloft.

Step 4:

As the kite flies upward, slowly release more line.







OPTIMUM WIND CONDITIONS FOR ZOMBIE KITE

